








* A Rivet Setter Osborne No. 89 or 170.
* Side Cutting Nippers Osborne No. 3377.
* Hole cutter No. 245.
* Copper Rivets and Burrs Osborne No. 1700.

Tools Needed

* Rawhide or wooden mallet Osborne No. 395 or 89.5
* Cutting block Osborne No. 603



LEATHER USED IN DEMONSTRATION. RIVETS CAN BE USED WITH OTHER MATERIALS

[Read More](#)

Price: \$0.00

Product Description